



**Haval GWM Cannon Alpha ute fitted with a Roll R Cover part numbers starting with GCA4.
Front of the ute tub guidance on the drilling points.**



Haval GWM Cannon Alpha ute fitted with a Roll R Cover part numbers starting with GCA4.
Front of the ute tub guidance on the drilling points.




1

FRONT TEMPLATE
PASSENGER SIDE



2

FRONT TEMPLATE
DRIVER SIDE





INSTALLATION INSTRUCTIONS

GWM CANNON ALPHA LOAD Rack to suit Roll R Cover (FRONT OF UTE TUB)



This instruction may refer to only one side of the vehicle or one side of a two-part component; repeat the steps for the other side where necessary.

All illustrations are for reference only and may not correspond to your specific vehicle.



Application list:

Haval GWM Cannon ute, GWM Cannon Alpha, LDV T60, Isuzu Dmax 2021+, Mazda BT50 2021+, Nissan Navara 2020+, Toyota Hilux A & J Deck 2016+.

INSTALLATION TIME:90minutes (Approximately)

IMPORTANT	• Do not exceed load limit indicated by manufacture. • If contact with volatile chemicals occur, clean bars with mild detergent and water solution	
Care Instructions	• Read Instructions fully before commencing installation. • Clean with a mild detergent and water solution • Do not use abrasive cleaners or solvents • Refer to manufactures instructions applicable to power drill. • Protect surface against scratches during installation process.	
Maintenance	Refer to Maintenance instructions.	
Tools Required	• Pen / Marker • Soapy water solution • Allen Key set • Screw driver • Trim Removal Tool	• Scissors & Knife • Spanner & Socket • Tape measure

PERSONAL PROTECTIVE EQUIPMENT:



Rubber Gloves



Goggles




Hearing Protection

BOX CONTENTS


PART NO. LR-AE001-1466mm (LOAD RACK CROSS BAR) Qty - 1




PART NO. S2.5-DC-RE-007-1550mm (Cross Bar Rubber) Qty - 1



PART NO. LR-RE-001 1500mm (LADDER RACK channel insert seal) Qty - 2



PART NO. LR-ASS-008 LEG Qty - 2



Pack 1

LR-PI-001



END CAP
Qty - 2




SELF
DRILLING
SCREW
Qty - 2



M8 HEX NUT
Qty - 8



M8 SPRING
WASHER
Qty - 8



M8x20mm
H5 Allen head,
Qty-8



M8x25mm H5
Allen head, with
spring washer &
mudguard flat
Washer
Qty-4



M6x12mm
SOCKET
HEAD BOLT
Qty - 4


LR-SM-001



CHANNEL
NUT
Qty - 2




S5 ALLEN KEY
Qty - 1




LR-FG-005
Foam Foot
PAD
Qty - 2


Pack 5



LR-ASS-006
LH Sleeve
FMB
Qty - 1



LR-ASS-006
RH Sleeve
FMB
Qty - 1




LR SPACER
Qty - 2




M8x25mm H5
Allen head, with
spring washer &
mudguard flat
Washer
Qty-4



SELF
DRILLING
SCREW
Qty - 20



LR-FG-004
Foam
Sleeve PAD
Qty - 2



The load rack cross bar has a wide and a narrow face.

1. On the wide face, use the rubber molding (S2.5-DC-RE-007) and push it into the channel of the cross bars. Ensure it is flush with each end, avoiding any stretching of the rubber molding.
2. On both narrow faces, use the rubber molding (LR-RE-001) and push it into the channel of the cross bars. Ensure it is flush with each end, avoiding any stretching of the rubber molding.
3. Trim any excess rubber molding that hangs out

LR-RE-001

S2.5-DC-RE-007


LR-RE-001



S2.5-DC-RE-007



LR-RE-001



Turn the cross bar around so that the wide face without rubber molding is facing you

- a. Feed 2 channel nuts (LR-SM-001) into the indicated channel.
- b. In the indicated orientation, push end caps (LR-PI-001) all the way in to the extrusions both ends.
- c. Using the provided self-drilling screw, carefully secure the end cap into position by drilling through the end cap plastic tab and into the cross bar at the indicated location.

c


b

LR-PI-001

c

a

LR-SM-001



LR-PI-001




b

The upright legs (LR-ASS-008 LEG) of the ladder racks are adjustable. When assembled along with the cross bar on top of the ute tub or roll top, **they range from a minimum height of 450mm to a maximum height of 700mm.**

As a guide, measure from the top of the ute tub's headboard to the center height of the ute cabin. Use this measurement to determine how much higher you want the top of the rack to sit above the cabin roof, noting that the legs can be adjusted in **25mm** increments plus/minus.

It is recommended, but not necessary, to set your height at this point. Once you have chosen the desired height, lock it into place by following these steps:



- On the outer sleeve of the leg, choose the top holes as indicated. Feed the supplied M8x20mm Allen head bolt through the holes of both sleeves of the uprights. Secure it in place using an M8 spring washer and an M8 nut.
- On the inner sleeve of the leg, choose the bottom holes as indicated. Feed the supplied M8x20mm Allen head bolt through the holes of both sleeves of the uprights. Secure it in place using an M8 spring washer and an M8 nut.



When assembled with the crossbar on top of the ute tub or roll top, the height will range from a minimum of 450mm to a maximum of 700mm, increasing in 25mm increments from the lowest height.



Using the foam pad (LR-FG-005 Foam Foot PAD), apply it to the base of the leg as indicated







IF YOUR ROLL R COVER IS NOT FITTED TO THE VEHICLE PLEASE SKIP NEXT TWO STEPS





ROLL R COVER PREPERATION

1. Loosen and remove all three clamps or any bolts that are securing the clamp bracket of the roll covers to the ute tub.
2. Take out the drainage point from the canister.



With aid Remove Roll-R-Cover unit from the ute tub.






4 People
Recommended for lift

To identify the drilling points on your roll cover side rails, locate two points on the underside that are connected by a straight line. Drill these points using a 12mm drill bit.

If your side rails do not have these markings, please consult the vehicle-specific template provided in the kit for guidance on the drilling points.



Exercise caution while drilling to ensure that the swarf remains clear of the curtain.



NOTE: THIS STEP ONLY APPLIES
TO ROLL R COVER UNITS WITH
SERIAL NUMBERS ABOVE 32984



**Use the provided templates for vehicles fitted with a Roll R Cover.
Locate and utilize the vehicle-specific template from the kit to guide the drilling points.**

Position the front corners of the cut-out templates in line with the outer front corner of the track, ensuring that the vertical edge of the template is snug against the track. Mark the drilling locations to the side rails.

FRONT LOAD RACK

TEMPLATE

TEMPLATE






Exercise caution while drilling to ensure that the swarf remains clear of the curtain.



VEHICLE TAILGATE

Drill the locations marked on the side rails using a 12mm drill bit.




Tub preparation



If your ute bed is equipped with factory bolts to the locations indicated, please skip to page 11 of 22.



If your ute bed is equipped with factory bolts to the locations indicated, please skip to page 11 of 22.



1. Position the LR Spacer on the top rail of the ute tub
2. Place bracket (LR-ASS-006 LH Sleeve FMB) over LR spacer and center to the tabs of the bracket.



LR SPACER is **TO BE USED ONLY** for the **GWM Cannon ute, LDV T60 & MV Mitsubishi Triton** vehicles. If you are working with a different vehicle, please ignore the LR Spacer part, and proceed with only installing LR-ASS-006 LH Sleeve FMB.



LR SPACER




1




LR-ASS-006 LH sleeve FMB

2




Position the bracket (LR-ASS-006 LH Sleeve FMB) on both the headboard and the top of the side panel of the tub. Apply firm downward pressure on the brackets. Secure the bracket to the indicated locations using self-drilling screws, aligning them with the center of the elongated holes. If there is an obstruction, choose any of the other elongated holes to drill through into the ute tub inner bed rail.

Note: If required you may loosen the screws to adjust the bracket upward / downward, then tighten them again.
SPECIAL NOTE FOR J Deck Toyota Hilux: Bracket will line up against the front bar assemblies top lip.





Now secure the bracket tight using the self drilling screws to the indicated locations.



Tub preparation

Remove indicated bolts (or in-case of Nissan there will be only one bolt) and discard.




1. Position the LR Spacer on the top rail of the ute tub
2. Place bracket (LR-ASS-006 LH Sleeve FMB) over LR spacer and center to the tabs of the bracket.

LR SPACER is **TO BE USED ONLY** for the **GWM Cannon ute, LDV T60 & MV Mitsubishi Triton** vehicles. If you are working with a different vehicle, please ignore the LR Spacer part, and proceed with only installing LR-ASS-006 LH Sleeve FMB.




LR SPACER



1

LR SPACER




Ute tub top rail

LR-ASS-006 LH Sleeve FMB


SECTION VIEW - SIDE

LR-ASS-006 LH Sleeve FMB


2





1. Align the elongated holes at the front of bracket LR-ASS-006 LH Sleeve FMB with the thread of the tub. Apply firm downward pressure to secure the bracket, then fasten it in place using the provided M8x25mm Allen head bolt which has the spring washer and mudguard washer loaded to it.
2. Fasten rear of bracket using self-drilling screws, aligning them with the center of the indicated elongated holes.




Now secure the bracket tight using the self drilling screws to the indicated locations.




Apply the foam pad (LR-FG-004 Foam Sleeve Pad) to the top of the bracket as indicated, aligning the holes on the foam pad with the center of the threads on the bracket.




With caution and assistance, carefully place the Roll R Cover back onto the top rail of the ute tub, ensuring not to cause any damage. Stop just before reaching the load rack base brackets.




4 People
Recommended for lift




Exercise caution and seek assistance as needed. Gently raise the side rails and shift the roller cover forward, allowing the motor and driver side rail to fit between the load rack's base brackets. Depending on the situation, it may be necessary for two individuals to lift the rear of the side rails to prevent any collisions between the side rail clamp brackets and the ute tub.





4 People
Recommended for lift



Completed View.




With care, pull out any side rubber that has folded under the side rail.




With the tailgate up (Closed position), Pull left & right hand side rails towards the tailgate, stopping short by 7mm between tailgate and side-rail endcap.

7mm





Foam compressed to 7mm when tailgate is closed.




1. Center the holes of the side rails to the thread of the bracket below.
2. Apply a thin layer of sealant to the holes on the side rail.
Repeat to the other side.





With care, and ensuring to avoid the edges of the side rails' rubber seal, place the Load rack leg (LR-ASS-008 LEG) on top of the side rails. Align the elongated holes with the threads of the base brackets. Secure it loosely in position using the supplied M8x25mm Allen head bolt, which has the spring washer and mudguard washer attached. Repeat to the other side.






1. As indicated place the assembled cross bar to the upright legs. You will need to align the channel nut to the upright legs pre drilled holes.
2. Secure it loosely in position using the supplied M6x12mm socket head bolt which has the spring washer already loaded.



1. Measure and center cross bar.
2. Make sure uprights are parallel and the elongated holes of the uprights are as close to centered to the thread of the base bracket, ensuring to avoid the edges of the side rails' rubber seal.





While maintaining alignment, firmly tighten all specified bolts at location **a** followed by **b**.
Securely tighten all bolts to 8nm torque.




Position clamp behind the inner top lip of the bed rail and the **center elongated** hole of the side rail mounting brackets. Repeat to all 6 positions.




Ensure the M8 nut is in the indicated slot of the clamp




Fasten clamp loosely into position using M8 washer, M8 spring washer and M8 x 35mm bolt.




1. Apply downward pressure on side rails.
2. Lift **clamp** all the way up or as far up as possible then fasten clamp to 14Nm torque in the order indicated below.




Feed M8 nut into M8x70mm bolt and through clamp bracket's pre-installed nutsurt as indicated.



Side rail rubber to sit 1mm below from the top of the tailgate in the closed position.



Fasten the M8 nut against clamp bracket.



NOTE: The Load rack is rated to carry 60kg combined.
Exceeding the manufacturers recommended limit may cause issues
and result to canceling of your warranty.



Please read the following disclaimer carefully before using our load racks. By using our load racks, you acknowledge and agree to the terms and conditions stated below.

Load Rack Ratings:

Our load rack system consists of a front rack and a rear rack, each with a maximum load capacity of 60kg. When the front and rear racks are coupled with the accessories bar, the combined load capacity is rated up to 150kg. These weight ratings apply solely to the racks themselves.

Vehicle Manufacturer's Guidelines:

It is essential to consult your vehicle manufacturer's guidelines to determine the permissible carrying capacity once our load racks are installed. The load-carrying capacity of your vehicle may vary, and it is crucial to adhere to the specific guidelines provided by the manufacturer. Please note that these guidelines may override the load capacity ratings of our load racks.

Consumer Guarantees:

Under the Australian Consumer Law, our load racks come with guarantees that cannot be excluded, including guarantees as to acceptable quality and fitness for purpose. You may be entitled to a replacement, repair, or refund if our load racks do not meet these guarantees. These consumer guarantees apply in addition to any other warranties or disclaimers stated in this disclaimer.

Limitation of Liability:

To the extent permitted by law, HSP (hereinafter referred to as "we," "our," or "us") will not be held liable for any damages or losses incurred to your vehicle or any third-party property as a result of using our load racks. It is the responsibility of the user to ensure that the load being carried is within the prescribed weight limits, securely fastened, and properly distributed.

Proper Installation and Usage:

We strongly recommend that you carefully follow the installation instructions provided with our load racks. Improper installation or usage may lead to instability, damage to your vehicle, or accidents. It is your responsibility to ensure that the load racks are correctly installed and used in accordance with the provided instructions.

Regular Inspections and Maintenance:

We advise conducting regular inspections of the load racks to check for any signs of wear, damage, or loose components. If any issues are detected, discontinue use immediately and seek professional assistance. Regular maintenance is essential to ensure the continued safe and proper functioning of the load racks.

Assumption of Risk:

By using our load racks, you acknowledge and accept the inherent risks associated with carrying loads on your vehicle. You assume all responsibility for any damages, injuries, or losses that may arise from the use of our load racks, whether directly or indirectly.

Tub Strengthening Requirements:

Please be aware that your vehicle manufacturer may require additional strengthening of the tub in certain cases. This responsibility falls on the user/purchaser, and it is crucial to comply with such requirements as specified by your vehicle manufacturer.

Please note that this disclaimer does not exclude, limit, or modify any rights or remedies available to you under the Australian Consumer Law or any other applicable legislation. If you have any questions or concerns regarding our load racks or your consumer rights, please contact us or seek independent legal advice.

If you do not agree with any part of this disclaimer or if any provision of this disclaimer is held to be invalid or unenforceable, the remaining provisions will continue in full force and effect.

If you have any questions or concerns regarding our load racks or this disclaimer, please contact us for further clarification.